Section 70 Driveways & Walkways

- A. Surfaces must be consistent with original materials and colors.
- B. Walkways from the driveway to front door; front and rear patios and porches may be considered for resurfacing (tile, pavers, etc.,)
- C. Driveways should remain free from oil, gas and other stains. Periodic cleaning may be required at the discretion of the Board of Directors.
- D. No side extensions to the driveways or walkways are allowed.
- E. Driveway extensions may be considered provided:
 - 1. ARC application submitted and approved.
 - 2. Appropriate permitting obtained by homeowner/contractor (permit applicationType 1).
 - 3. Pavers/extension are professionally installed.
 - 4. Pavers match existing...TREMRON OLDE TOWN 2 PIECE AUTUMN BLEND.
 - 5. In order to maintain the appearance and symmetry of the community:
 - a. Maximum extension width permitted will be 7 feet.
 - b. Width distribution shall be approximately 7 ft toward entry way, to plane of walkway.
 - c. Pavers shall extend to road and meet plane of existing pavers.
 - d. Pavers must be intermixed (Existing pavers must be lifted and randomly intermixed with the new pavers over the entire area.)
 - e. See graphic and further specification information in Appendix I of this document.
 - 6. Homeowner is responsible for relocating all necessary irrigation.

APPENDIX I.

Abbington Homeowners Association recommendations for extension of paver driveway

- 1. Decide/calculate required square feet of pavers needed for install
 - ➤ Maximum width permitted is feet
 - Approximately 7 feet toward entry walkway to plane of walkway
- 2. Locate appropriate professional for installation.
- 3. Obtain ARC approval & Appropriate permitting per county requirements (permit application type I)
- 4. Pavers may be obtained via Pompanoorders@tremron.com
 - ➤ Tremron Group (only)
 - 1251 N.E. 48th Street, Pompano Beach, Fl 33064, 954.418.0000
 - PV21385W1004A Olde Towne 2 Piece
 - ✓ Thickness 2 3/8
 - ✓ Color Autumn Blend
 - ✓ Finish Standard
 - ✓ Unit price (current) Approximately \$1.55 per square foot excluding delivery and labor.
- 5. Do not start any work until the pavers are screening mix are delivered to your home.
- 6. Remove any turf, irrigation and decomposed soil for compaction.
 - ➤ Relocate irrigation system/lines to the new edge of the pavers.
- 7. String line the area of work.
 - ➤ Sub-base grade 3 ½ inches from finished pavers.
 - ➤ Maintain the same slope of existing driveway.
 - Use a plate compactor 23" x 19" or similar.
 - Use water for better ground density.
- 8. Add approximately 1.5 inch of concrete screening mix.
 - > Run compactor one more time.
 - ➤ Use more water moderately for density (2.00) g/cm³
- 9. Final grading to start paver install
 - \geq 2 $\frac{2}{3}$ below string line.
- 10. Install paver @ 90 degree pattern
 - ➤ Lock paver area with concrete border.
 - > Spread play sand evenly over entire paver area.
 - ➤ Run the compactor over the sand for corrections on any imperfections.
 - Remove extra sand.
 - ➤ Hose down pavers.

Approximate appearance of driveway extension per above specifications

